HOW TO INSTALL [COIN & CARD]





- Using by 7001 key, open 1~4P front door and then take out coins after open the coin box using by 6001 key.

2



- Detach the cover after unlocking bolts in front and side of elevator hopper cover.



- Put 1000 coins each for 1P ~ 4P in Front Hopper.



- Then, push select button among SET UP buttons and perform Perform by pushing Select button as OPERATION MENU / PLAYFIELD SETUP / TABLE SET.A in order.



- After selecting 1P ~ 4P PLAYER, supply 1000 coins to PUSHER BASE PANEL by Hopper. 5



- Then, put some of cards, which is included in Accessart Part, onto CARD DISPENSER and then lay H frame to fix it.



- Complete the supply of coins and cards as like picture 6.
- * On initial setting, put some of cards onto PUSHER BASE PANEL then finish the setting.

7

- On column **6**, Set 10~12 cards above coins supplied on PUSHER BASE PANEL as like the picture.

Then, maintain 8~10 cards on playing.